


# RIM-750 Troubleshooting via External Buttons and LED




Thank you for purchasing the Remote Infrastructure Management (RIM-750) System from Chatsworth Products (CPI). It's external LED and two buttons have been programmed to help you troubleshoot and reset the system. Use this guide to maximize this functionality.

If, after referencing this guide, you need further assistance with the RIM-750, please visit [www.chatsworth.com/Products/Environmental-Monitoring-and-Security/RIM-750/](http://www.chatsworth.com/Products/Environmental-Monitoring-and-Security/RIM-750/), email technical support at (techsupport@chatsworth.com) or call us at +1-800-834-4969.

## RIM-750 - Front View



## RIM-750 - Rear View



## External Indicators & Buttons

The RIM-750 has one multi-color LED and two push button. The LED is programmed to report a variety of conditions, and the buttons allow you to execute a variety of system and configuration reset options.

### Status LED

The RIM-750 has one multi-color LED on its front side. There are a variety of alarm and alert patterns and colors programmed for this LED. Use the following chart to determine which alarms are active on your RIM-750.

Blink Pattern	Pattern Description	Status Description
■ ■ ■ ■	Solid Green	Normal status - no alarms are present
■ ■ ■ ■	Light blue / Dark blue	Alarm - Leak detection cable break
■ ■ ■ ■	Light blue / Off	Alarm - A leak has been detected
■ ■ ■ ■	Red / Off	Alarm - Temperature
■ ■ ■ ■	Red / Dark blue	Alarm - Humidity
■ ■ ■ ■	Magenta / Off	Alarm - Digital input
■ ■ ■ ■	Yellow / Off	No Network Connection
■ ■ ■ ■	Yellow / Magenta	Debug connection is active
■ ■ ■ ■	Yellow / Light blue	Configuration mode is active
■ ■ ■ ■	White / Off	Unit is booting*
■ ■ ■ ■	Red / Green / Blue / Magenta	Firmware update is executing*
■ ■ ■ ■	Red / Magenta	Call CPI- the RIM-750 has an internal error

\* Do not access or configure the RIM-750 while these alerts are active.

## Alarm Silence and System Reset Button

The alarm reset is located on the front of the unit, near the LED. When the audible alarm is active, push this button once to silence the audible alarm. You'll know which alarm is active and associated with the audible alarm because the LED will blink to indicate a specific alarm condition.

There are several more reset functions assigned to this button. Press the button (and hold when indicated) to achieve the desired functions:

Press Button and Release	LED Color	Action
One quick beep	Blinking LED error indicator	Silence audible alarm
Press Button and Hold; Release After	LED Color	Action
Two consecutive beeps	Green	Reset all alarms. If any alarms are currently active, they will immediately re-alarm.
Three consecutive beeps	Red	Toggle the relay output
Four consecutive beeps	White	Reboot the RIM-750

## Configuration Button

There is also a small button on the back of the unit, between the terminal blocks for the digital inputs and leak detection leader cable. This button needs to be accessed with the tip of a small object, like a paperclip - insert it into the hole and press the button (and hold when indicated) to achieve the desired functions:

Press Button and Release	Action
One beep	Enable DHCP. The unit will remain this way until the IP is configured or the unit is rebooted. This action also resets the RIM-750's NetBios name to the device's serial number, so you can access the device on a local network by typing <code>cpi-serialnumber/</code> in your browser's address bar.
Press Button and Hold; Release After	Action
Two consecutive beeps	Set a default Static IP. The unit will remain this way until the IP is configured or the unit is rebooted.
Three consecutive beeps	Disables the administrator password.
Four consecutive beeps	Reset to all factory default settings
Hold for 20 seconds (solid tone)	Reset to factory firmware and all factory default settings

