

# Installation Instructions

## TERAFRAME LASHING BAR

### Tools Required

13mm socket wrench

### Parts List

- (1) Lashing panel
- (3) M8X12 bolts, flat washers, and drop-in nuts

### Installation Notes

- Lashing bar must be recessed a minimum of 2" from inside vertical edge to maintain access to frame grounding stud and easy tie down access

### Assembly Sequence

1. Position the Lashing bar at the desired location.
2. Insert M8 drop-in nuts in the slides as shown. Attach the bracket to the top middle, and bottom of the frame with 3 M8X12 bolts, flat washers and drop in nuts.

