

# Installation Instructions

## TERAFRAME POWER/LASHING BRACKET

### Tools Required

13mm socket wrench

### Parts List

- (1) Power/ Lashing bracket
- (4) M8X12 bolts, flat washers, and drop-in nuts

### Installation Notes

- The Power strip bracket holds up to two CPI 66" or 38" cabinet power strips.

### Assembly Sequence

1. Position the power strip bracket near the front or back vertical frame member.
2. Insert M8 drop-in nuts in the slides as shown. Attach the bracket to the top and bottom of the frame with 4 M8X12 bolts, flat washers and drop in nuts.

