

Installation Instructions

RMR MODULAR GLAND BOTTOM PANEL

Safety Information



WARNING: Improper use of this product may lead to serious injury. Read and understand all instructions for proper installation and use of this product.

Tools Required

M10 Nut Driver

Included Hardware

- (4) M6 hex nut
- (4) Bottom clamp bracket

Assembly Sequence

1. Place the cabinet over the bottom panel. Orient grounding stud adjacent to front door.
2. Install (4) clamp brackets as shown using M6 hex nuts positioned toward side panel. Torque to 88in-lb [9.9N-M]

