



1. Using a utility knife, cut a foam strip length to fit under a lower edge of the cabinet.
2. Compress the foam under a lower edge of the cabinet to form an air dam that restricts air flow between the inside of the cabinet and the room.
3. Repeat for all exposed edges



INSTALLATION INSTRUCTION,  
ENCLOSURE FOAM GASKET  
KIT

THIS DRAWING CONTAINS INFORMATION PROPRIETARY TO CHATSWORTH PRODUCTS, INC. ANY REPRODUCTION DISCLOSURE OR USE OF THIS DRAWING IS EXPRESSLY FORBIDDEN EXCEPT AS AGREED TO IN WRITING BY CHATSWORTH PRODUCTS, INC.