

PATHWAY ELEVATION KIT, ZETAFRAME®

Included Hardware:

M8 Hammer Bolt, 2 ea.

M8 Serrated Flange Nut, 2 ea.

5/16-18 Hex Head Bolt, 4 ea. single or 8 ea. tiered

5/16-18 Serrated Flange Nut, 4 ea. single or 8 ea. tiered

Tools Required:

13mm socket

1/2in socket

Assembly Notes:

The Pathway Elevation Kit allows Cable Runway or Wire Tray to be installed above the ZetaFrame cabinet. The Pathway Elevation Kit is available at different elevation heights and for single or tiered pathways.

Installation Instructions:

The Pathway Elevation Kit attaches to the top cabinet slides.

1. Insert M8 hammer bolt into top slide channel and rotate 90 degrees.
2. Install elevation bracket using obround slot closest to the cabinet side. Secure using an M8 serrated flange nut.
3. Repeat steps 1 and 2 to attach second elevation bracket.
4. Use the clamp brackets and 5/16-18 hardware to mount cable runway to the elevation bracket.

Note: Hardware to mount wiretray is sold separately.

