

Installation Instructions

CUBE-IT LASHING BRACKET

Safety Information



WARNING: Improper use of this product may lead to serious injury. Read and understand all instructions for proper installation and use of this product.

Tools Required

10mm Socket or Box Wrench

Included Hardware

- (2) M6 Carriage Bolt
- (2) Star Washer
- (2) M6 Serrated Nut

Assembly Sequence

1. Place lashing bracket against rails with flange facing towards the back and outside as shown in the figure to the right.
2. Use provided hardware to fix manager in place as shown in diagrams to the right, tighten to finger tight.
3. Slide manager to desired position within slots.
4. Torque M6 Serrated Nut to 90 IN-LB [10 N-M].

