

Installation Instructions

PDU, Three Phase, Horizontal & Vertical 120/208V, WYE, 20A or 30A 250V, DELTA, 30A, 35A, 60A, 80A or 120A

Safety Information



WARNING: Improper use of this product may lead to serious injury or death. Read and understand all instructions for proper installation and use of this product.



CAUTION: Three Phase high power PDU's if improperly handled or connected can cause damage to the equipment connected to them.



CAUTION: The input plug of this power tap is intended to serve as the disconnect device, it shall be easily accessible and withdrawn.



CAUTION: Equipment connections to the power strip must adhere to the nameplate ratings listed otherwise an overload condition may cause damage to the protection circuitry and supply wiring.

Installation Guidelines

- Overcurrent protection is an element accounted for during the building/room design and installation. The PDU relies on adequate building overcurrent protection. Insure that UL listed circuit breakers are utilized for overcurrent protection.
- Install the PDU using qualified installation and service personnel.
- Install the PDU in cabinets with a temperature no greater than 45°C (113 °F).
- Do not inhibit cabinet airflow with the installation of the PDU.
- Avoid uneven mounting which could develop into a hazardous condition.
- Equipment plugged into this PDU should be grounded to a grounding bus separate from the branch circuit grounding bus.
- Ensure that the outlet plugs on the PDU are easily and readily accessible for interruption of service (disconnection). Do not block or obstruct access to the outlets in any way

- ALWAYS disconnect all input and output power cords on the PDU before servicing. Never install the PDU in a location where there may be a presence of water.
- Remove power to the PDU before removing existing or installing new equipment.
- PDU external Ground Wire is an enhanced feature for RFI and EMI noise reduction when required. Follow Grounding and Bonding methods when connecting the Ground Wire to the Racks and/or Cabinets at customer discretion.

Notes

- **Elevated Operating Ambient-** If installed in a closed or multi-unit rack assembly, the operating ambient temperature of the rack environment may be greater than room ambient. Consideration should be given to installing the equipment in an environment compatible with the maximum rated ambient temperature of 45°C (113 °F).
- **Reduced Air Flow** – Installation of the equipment in a rack should be such that the amount of airflow required for safe operation of the equipment is not compromised.
- **Mechanical Loading** – Mounting of the equipment in the rack should be such that a hazardous condition is not achieved due to uneven mechanical loading.
- **Circuit Overloading** – Consideration should be given to the connection of the equipment to the supply circuit and the effect that overloading of the circuits might have on overcurrent protection and supply wiring. Appropriate consideration of equipment nameplate ratings should be used when addressing this concern.
- **Reliable Earthing** – Reliable earthing of rack-mounted equipment should be maintained. Particular attention should be given to supply connections other than direct connections to the branch circuit.
- **Service Personnel** – Only service personnel should install and access this equipment.



CHATSWORTH PRODUCTS, INC.

IIS-735601, 12/07/09, Rev.4 V. Eisa

800-834-4969 • techsupport@chatsworth.com • www.chatsworth.com

This drawing contains proprietary and confidential information and is protected by U.S. and international law. Unauthorized reproduction, disclosure or use of the drawing or the information therein is expressly forbidden except as agreed to in writing by Chatsworth Products, Inc.

Installation

1. Mount PDU to rack/cabinet. Appropriate brackets and hardware are provided.
2. Ensure the rating of the PDU matches that of the branch circuit it is plugged into.
3. Connect 120/208V, WYE, rated PDU's to 120/208V, WYE, 20 AMP or 30 AMP circuits. Connect 250V, DELTA rated PDU's to 250V, DELTA 30, 35, 60, 80 or 120 Amp Circuits.
4. Test each PDU outlet with a multimeter to insure proper outlet voltage before plugging any equipment into the PDU.
5. Make sure equipment power is OFF before plugging into the PDU
6. In order to avoid current surge to the PDU, power up equipment in a sequential order.

CPI Part Numbers

This document applies to the following CPI part numbers

3561X-xxx 3563X-xxx 3567X-xxx
35811-xxx 35812-xxx 35814-xxx 35815-xxx

CPI Bracket Kits

024-735700-701 RBK Bracket kit for 2 and 4 post Racks
024-735700-702 CBK Bracket kit for MegaFrame Cabinets
024-735700-703 TBK Bracket kit for TeraFrame Cabinets

Note:

PDU current ratings have been de-rated in accordance with UL/NEC recommended guidelines.

Specifications

- UL 60950-1, CSA C22.2 60950-1-03
- 120/208 Volt, 3 Phase WYE @ 20 Amp, 50/60Hz power PDU de-rated to 16 amps
- 120/208 Volt, 3 Phase WYE @ 30 Amp, 50/60Hz power PDU de-rated to 24 amps
- 250 Volt, 3 Phase DELTA @ 20 Amp, 50/60Hz power PDU de-rated to 16 amps
- 250 Volt, 3 Phase DELTA @ 30 Amp, 50/60Hz power PDU de-rated to 24 amps
- 250 Volt, 3 Phase DELTA @ 35 Amp, 50/60Hz power PDU de-rated to 28 amps
- 250 Volt, 3 Phase DELTA @ 50 Amp, 50/60Hz power PDU de-rated to 40 amps
- 250 Volt, 3 Phase DELTA @ 60 Amp, 50/60Hz power PDU de-rated to 48 amps
- 250 Volt, 3 Phase DELTA @ 80 Amp, 50/60Hz power PDU de-rated to 64 amps
- 250 Volt, 3 Phase DELTA @ 120 Amp, 50/60Hz power PDU de-rated to 96 amps
- 120/208 Volt, 3 Phase WYE, 20 Amp PDU strip outlets – IEC C13, IEC C13 and IEC C19, IEC C13 AND NEMA 5-20R, NEMA 5-20R AND NEMA L6-20R, NEMA 6-20R or NEMA 5-20R
- 120/208 Volt, 3 Phase WYE, 30 Amp power strip outlets – IEC C13 and IEC C19, NEMA 6-20R or NEMA 5-20R
- 250 Volt, 3 Phase DELTA, 20 Amp PDU strip outlets – IEC C13, IEC C13 and IEC C19
- 250 Volt, 3 Phase DELTA, 30 Amp PDU strip outlets – IEC C13, IEC C13 and IEC C19
- 250 Volt, 3 Phase DELTA, 35 Amp power strip outlets – IEC C13 and IEC C19
- 250 Volt, 3 Phase DELTA, 50 Amp PDU strip outlets – IEC C113, IEC C13 and IEC C19
- 250 Volt, 3 Phase DELTA, 60 Amp PDU strip outlets – IEC C13, IEC C13 and IEC C19
- 250 Volt, 3 Phase DELTA, 80 Amp power strip outlets – IEC C19
- 250 Volt, 3 Phase DELTA, 120 Amp power strip outlets – NEMA L15-30R

Service and Maintenance

For additional information please visit <http://www.chatsworth.com/power-management>

There are NO field serviceable or maintained parts on or in this power strip. Opening of the PDU housing will void product warranty and UL listing.