

Installation Instructions

EQUIPMENT RAIL ASSEMBLY

Included Hardware:

M8 Nut, 6 ea.
M6 Cage Nut kit
M8 Drop-in-nut, 6 ea.
M8 Hex screw, 6 ea.
M8 Star washer, 6 ea.

Tools Required:

13mm socket wrench


Safety Information



WARNING: Failure to properly install equipment rails can result in improper rail grounding. Improper use of this product may lead to serious injury. Read and understand all instructions for proper installation and use of this product.


Assembly Note:

The equipment mounting rail must be setback a minimum distance 0.55" (14mm) when used with Air Dam (Fig.1)



Assembly Sequence

The Equipment Rail (Fig.2) attaches to the cabinet slides.



IIS-739030, 02/18/13, Rev. 2, CPI/JAG/AK

800-834-4969 (USA & Canada) • www.chatsworth.com • techsupport@chatsworth.com

For international phone numbers, see our website or contact CPI Tech Support.

This drawing contains proprietary and confidential information and is protected by U.S. and international law. Unauthorized reproduction, disclosure or use of the drawing or the information therein is expressly forbidden except as agreed to in writing by Chatsworth Products, Inc.

Installation Instructions

EQUIPMENT RAIL ASSEMBLY

Installation Instructions for Replacement Rails

1. Position Equipment Rail as shown (Fig 3).




Fig. 3
Top Sectional View

2. Fasten rail using three M8 Nuts onto three M8 bolts in frame slides (Fig 4 & 5)
3. Slide the Equipment Rail to desired position (Fig.1) and torque nuts to 372 In-Lbs. (42 NM).
4. Repeat above steps for other Equipment Rail. The slides are marked to help vertically align the rails.




Fig. 4
600mm Width Equipment
Rail assembly




Fig. 5
800mm Width Equipment
Rail assembly
(700mm similar)

Installation Instructions

EQUIPMENT RAIL ASSEMBLY

Installation Instructions for Extra pair of Rails

Use the M8 drop-in nut, M8 hex screw and M8 star washer for the extra pair of rail installation as shown below.

Assembly Note:

For replacement rails use the existing bolts (and follow the procedure 1 to 4), to add an extra pair of rails to cabinet follow procedure 5 to 7.

- 5. Insert M8 Drop-In-Nut in lower T-slots of the slide (Fig.6).




Fig.6
M6 Drop-In-Nut Installation

- 6. Fasten the Equipment rail using M8 star washer and M8 hex screw onto M8 drop-in nut (see Fig.7). Torque screw to 250 In-Lbs. (28.3 NM).
- 7. Repeat above steps for 700mm and 800mm Equipment Rail(see Fig.8 and 9).




Fig. 7
600mm Width
Equipment Rail assembly




Fig. 8
700mm Width
Equipment Rail assembly

Fig. 9
800mm Width
Equipment Rail assembly