

Installation Instructions

N-SERIES TERAFRAME EQUIPMENT RAIL

Safety Information



WARNING: Failure to properly install equipment rails can result in improper rail grounding. Improper use of this product may lead to serious injury. Read and understand all instructions for proper installation and use of this product.

Included Hardware:

M8 Nut, 4 ea.
M8 Washer, 4 ea.
M8 X 12mm HH Screw, 4 ea.
M8 Drop-In Nut, 4 ea.

Tools Required:

13mm socket wrench

Assembly Note:

The equipment mounting rail must be setback a minimum distance when used with Cable Fingers (Fig.1).




Fig. 1
Top Sectional view

Assembly Sequence:

The Equipment Rail (Fig. 2) attaches to the cabinet slides.




Fig. 2
Equipment Rail



CHATSWORTH PRODUCTS

IIS-739328 01/09/14, Rev. 1, CPI/JAG

800-834-4969 (USA & Canada) • www.chatsworth.com • techsupport@chatsworth.com

For international phone numbers, see our website or contact CPI Tech Support.

This drawing contains proprietary and confidential information and is protected by U.S. and international law. Unauthorized reproduction, disclosure or use of the drawing or the information therein is expressly forbidden except as agreed to in writing by Chatsworth Products, Inc.

Installation Instructions

N-SERIES TERAFRAME EQUIPMENT RAIL

1. Position Equipment Rail as shown (Fig. 3).




Fig. 3
Top Sectional View

2. Fasten rail using two M8 Nuts onto two M8 bolts in frame slides (Fig.4).
3. Slide the Equipment Rail to desired position (Fig. 1) and torque nuts to 372 In-Lbs. (42 NM).
4. Repeat above steps for other Equipment rail. The slides are marked to help vertically align the rails.




Fig. 4
Equipment Rail assembly

Installation Instructions

N-SERIES TERAFRAME EQUIPMENT RAIL

Option 2: Equipment Rail installation with Drop-In-Nut

1. Insert Drop-In Nuts in slides (Fig. 5)




Fig. 5
M8 Drop-In-Nut Installation

2. Fasten rail using two M8 Screws and lock washers onto two M8 Drop-In Nuts in frame slides (Fig.6).
3. Slide the Equipment Rail to desired position (Fig. 1) and torque nuts to 372 In-Lbs. (42 NM).
4. Repeat above steps for other Equipment rail. The slides are marked to help vertically align the rails.




Fig. 6
Equipment Rail assembly
With Drop-In-Nut